


# Internal Picture

Internal view of EUT



Internal view of EUT






Internal view of EUT




Front view of PCB



Front view of PCB




Front view of PCB







Back view of PCB



Internal battery pack (EVE PL401223GH)



Internal battery pack (Everpower PL401224H)



Internal battery pack (ATL PL401323)

